



**NOTES:**

1. HAND CHAIN INTERLOCK SWITCH ON HAND CHAIN MODELS.
2. VOLTAGE SAME AS LINE VOLTAGE.
3. MOVE RED WIRE FROM 3 TO 2 FOR CONSTANT PRESSURE TO CLOSE.
4. USE COPPER WIRING ONLY ON FIELD WIRING TERMINALS.
5. DPDT SWITCH OR TWO (2) SPDT SWITCHES. C MODEL LIMITS NOT AS SHOWN.

CONNECT REVERSING EDGE AND TEST MONTHLY.

CAUTION: DISCONNECT POWER BEFORE ATTEMPTING SERVICE OR ADJUSTMENTS.

Standard Wiring Models J,H,MO,GT,MGH,AU & C  
Reverse Limits Model T

				c.p. ALLSTAR CORPORATION PO Box 240 Downingtown, PA 19335			
				APPRV. BY	SHEET	DRAWN BY	REV
	1 OF 1	DATE	5-17-96	E			
TITLE				DRAWING NO.			
WRG DIAG,CDO,3P,B2,STNDRD				106848			