

eMerge 50P and 5000P Cross-Reference Model Part Numbers

Model	Description	Old Part #	Status	Replacement Part #
eMerge Browser-Managed Access Systems				
eMerge50	eMerge50 Access Control Platform	230219	DISCONTINUED	230219P
eM50R2Pack	eMerge50 Access Control Platform & Reader Bundle	230219PACK	DISCONTINUED	230219P + (2) 0-299100
eMerge5000	eMerge5000 Access Control Platform	230220	DISCONTINUED	230220P
eM5000R2Pack	eMerge5000 Access Control Platform & Reader Bundle	230220PACK	DISCONTINUED	230220P + (2) 0-299100
NOTE: "P" models provide 5 AMP power supply - enough power for full can with application cards and 12 VDC 50mls for readers				
eMerge Expansion Housings and Application Blades				
eMACMR2Pack	eMerge Access Control Blade & Reader Bundle	0-580100-LPACK	Active	same as previous
eMergeACM	eMerge Access Control Blade	0-580100-L	Active	same as previous
eMergeCF2G	eMerge Memory Card	230218	Active	Only for 3.3 Systems
eMergeEXN	eMerge Expansion Node	0-587004	Active	same as previous
eMergeEXNLPS	eMerge Expansion Node with Line Power	0-589004	Active	same as previous
eMergeINP	eMerge Input Blade	0-580110	Active	same as previous
eMerge MicroNode	eMerge MicroNode	230222	Active	same as previous
NOTE: All the "P" models are Micronode-compatible; No added license required.				
eMergeOUT	eMerge Output Blade	0-580120	Active	same as previous
eMergeTMP	eMerge Temperature Monitoring Blade	0-580130	Active	same as previous
eMergeTMPPB	eMerge Temperature Monitoring Probe	0-580131	Active	same as previous
eMerge Spare Parts				
eMergeNCB v2.5	eMerge Spare Network Controller Board	0-587008	DISCONTINUED	See below
eMergeNCB v3.3	eMerge Spare Network Controller Board	230338	Limited Replacement*	620-100385 = 50P Takeover 620-100387 = 5000P Takeover
eMergeNNB	eMerge Spare Network Node Board	0-587009	Active	same as previous
eMergeNCBV3.3	eMerge 5000 Combo Board Replacement	230338	Active	620-100384
eMerge50P TAKEOVR	eMerge 50P Takeover Kit **NEW!**	n/a	Active	620-100385
eMerge5000P TAKEOVR	eMerge 5000P Takeover Kit **NEW!**	n/a	Active	620-100387
eMerge Software, Licenses and Upgrades				
eMergeAPI	eMerge API License	2-067009	DISCONTINUED	none
eMergeBD2	eMerge Badge Designer and Printing Station License	2-067006	Active only for 3.3 Systems	620-100389 5000P
eMergeLMB	eMerge Live Monitoring License	2-067008	DISCONTINUED	none
eMergeU5000	eMerge 50 to 5000 Upgrade	230344	Only on 3.3 systems	same as previous
eMergeVMS1E	eMerge Single Camera Expansion License	eMergeVMS1E	Only on 3.3 systems	same as previous
eMergeVMS8B	eMerge Base Video Management License	eMergeVMS8B	Only on 3.3 systems	same as previous
eMergeU52	eMerge 5000P 52-door license upgrade	n/a	Active	620-100346
eMergeVMS8E	eMerge Expansion Video Management License	eMergeVMS8E	Only on 3.3 systems	same as previous
eMerge Professional Services				
eMergeCDMB	eMerge Data Migration Service	eMergeCDMB	Active	n/a
eMergeCOMB	eMerge System Commissioning	eMergeCOMB	Active	n/a

eMerge 50P and 5000P
Cross-Reference Model Part Numbers

Features	eMerge 50P	eMerge 5000P
# of Doors	32	140 (Optional upgrade to 192)
Card Holders	5,000	20,000
Camera View	64	256
Email / SMS	•	•
NAS / FTP	•	•
Burg Interface Loops	•	•
Set up Wizards	•	•
Micro Node Enabled	•	•
Widget Desk Top	•	•
Elevator Control		•
Badging		•
User Roles		•
Custom Reports		•
Threat Levels		•
VMS	Optional	Optional