











# AE-100 PROGRAMMING WORKSHEET

STANDARD PROGRAMMING OPTION WORKSHEET			
PPN #	USAGE	FACTORY DEFAULT	CUSTOM SETTING
01	CHANGE MASTER PASSWORD	123456	_____ MASTER PASSWORD (6-DIGITS)
02	DIRECTORY CODE LENGTH	3 DIGITS	<input type="checkbox"/> 2 DIGITS <input type="checkbox"/> 3 DIGITS
07	SET SUB-UNIT NUMBERS	NOT SET	<input type="checkbox"/> UNIT 2 <input type="checkbox"/> UNIT 3 <input type="checkbox"/> UNIT 4
38	SYSTEM DISPLAY LANGUAGE	ENGLISH	<input type="checkbox"/> ENGLISH <input type="checkbox"/> SPANISH <input type="checkbox"/> FRENCH <input type="checkbox"/> PORTUGUESE
51	KEYPAD LOCKOUT COUNT	3 TRIES BEFORE LOCKOUT	<input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> 4 <input type="checkbox"/> 5 <input type="checkbox"/> 6 <input type="checkbox"/> 7 <input type="checkbox"/> 8 <input type="checkbox"/> 9
52	ACCESS RELAY ACTIVATION TIME	4 SECONDS	_____ SECONDS (4-99 SECONDS)
57	WELCOME DISPLAY TEXT	LINEAR ACCESS TELEPHONE ENTRY	
61	AUTOMATIC TELEPHONE ANSWER	AUTO ANSWER ON	<input type="checkbox"/> AUTO ANSWER ON <input type="checkbox"/> AUTO ANSWER OFF
62	SPEAKER CHIRP ON KEYSTROKES	SPEAKER CHIRPS ON	<input type="checkbox"/> SPEAKER CHIRPS ON <input type="checkbox"/> SPEAKER CHIRPS OFF
63	SPEAKER TONE ON RELAY ACTIVATION	SPEAKER TONE ON	<input type="checkbox"/> SPEAKER TONE ON <input type="checkbox"/> SPEAKER TONE OFF
64	MAXIMUM VISITOR TALK TIME	60 SECONDS	_____ SECONDS (10-180 SECONDS)
71	ASSIGN UNIT NUMBER	UNIT NUMBER 1	<input type="checkbox"/> UNIT 1 <input type="checkbox"/> UNIT 2 <input type="checkbox"/> UNIT 3 <input type="checkbox"/> UNIT 4
77	RESIDENT CONTROL OF ACCESS RELAY	RESIDENT CONTROL ON	<input type="checkbox"/> RESIDENT CONTROL ON <input type="checkbox"/> RESIDENT CONTROL OFF
95	RESIDENT CALL-BACK	RESIDENT CALL-BACK OFF	<input type="checkbox"/> RESIDENT CALL-BACK ON <input type="checkbox"/> RESIDENT CALL-BACK OFF



**STANDARD  
PROGRAMMING  
METHOD**

**ALTERNATE  
PROGRAMMING  
METHOD**



ALTERNATE PROGRAMMING OPTION WORKSHEET			
FCN #	USAGE	FACTORY DEFAULT	CUSTOM SETTING
00	CHANGE MASTER PASSWORD	123456	_____ MASTER PASSWORD (6-DIGITS)
06	DIRECTORY CODE LENGTH	3 DIGITS	<input type="checkbox"/> 2 DIGITS <input type="checkbox"/> 3 DIGITS
07	SET SUB-UNIT NUMBERS	NOT SET	<input type="checkbox"/> UNIT 2 <input type="checkbox"/> UNIT 3 <input type="checkbox"/> UNIT 4
08	ASSIGN UNIT NUMBER	UNIT NUMBER 1	<input type="checkbox"/> UNIT 1 <input type="checkbox"/> UNIT 2 <input type="checkbox"/> UNIT 3 <input type="checkbox"/> UNIT 4
10	WELCOME DISPLAY TEXT	LINEAR ACCESS TELEPHONE ENTRY	
38	SYSTEM DISPLAY LANGUAGE	ENGLISH	<input type="checkbox"/> ENGLISH <input type="checkbox"/> SPANISH <input type="checkbox"/> FRENCH <input type="checkbox"/> PORTUGUESE
70	MAXIMUM VISITOR TALK TIME	60 SECONDS	_____ SECONDS (10-180 SECONDS)
71	ACCESS RELAY ACTIVATION TIME	4 SECONDS	_____ SECONDS (4-99 SECONDS)
72	KEYPAD LOCKOUT COUNT	3 TRIES BEFORE LOCKOUT	<input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> 4 <input type="checkbox"/> 5 <input type="checkbox"/> 6 <input type="checkbox"/> 7 <input type="checkbox"/> 8 <input type="checkbox"/> 9
74	AUTOMATIC TELEPHONE ANSWER	AUTO ANSWER ON	<input type="checkbox"/> AUTO ANSWER ON <input type="checkbox"/> AUTO ANSWER OFF
75	SPEAKER CHIRP ON KEYSTROKES	SPEAKER CHIRPS ON	<input type="checkbox"/> SPEAKER CHIRPS ON <input type="checkbox"/> SPEAKER CHIRPS OFF
76	SPEAKER TONE ON RELAY ACTIVATION	SPEAKER TONE ON	<input type="checkbox"/> SPEAKER TONE ON <input type="checkbox"/> SPEAKER TONE OFF
77	RESIDENT CONTROL OF ACCESS RELAY	RESIDENT CONTROL ON	<input type="checkbox"/> RESIDENT CONTROL ON <input type="checkbox"/> RESIDENT CONTROL OFF
95	RESIDENT CALL-BACK	RESIDENT CALL-BACK OFF	<input type="checkbox"/> RESIDENT CALL-BACK ON <input type="checkbox"/> RESIDENT CALL-BACK OFF